


LEGO


World City 4

7031







1




2




3




4




5






6




7









4




5







9



1








2




3








11



12



1



2




3




4




1




2



3



1




2



4




5



6



13




1




2




1




2




3







4



14







LEGO

World City





46033/4194023 © 2003 LEGO GROUP